


# DA-WM4200 INSTALLATION MANUAL



This manual is intended for users of the DA-WM4200 wall mounting bracket. It includes instructions for mounting the DA-WM4200 wall mounting bracket to a wall.




- **This bracket is intended to be used with some models of dome cameras. Do not use it with other models of cameras.**
- **This installation should be performed by a qualified service personnel in conformance to all local codes.**
- **You may need to reinforce the wall. If the wall is not strong enough to support the camera, the camera may fall.**
- **Do not use this product for other purposes.**

## Mounting


### Mount the bracket to the wall as follows:

Mount bracket to the wall by using the anchors and screws.



### Connect your camera to the bracket as follows:

Assemble the camera body to the bracket by tightening the screws.



- 1 TC-D4222RX / TC-D4221RXP Model: Screw No.1 (2-point)
- 2 TC-D4211RX Model: Screw No.2 (3-point)
- 3 DC-D4236RX Model: Screw No.3 (2-point)
- 4 DC-D4216X / DC-D4216RX / TC-D5511RX Model: Screw No.4 (2-point)
- 5 DC-D4536RX / DC-D4217RX / TC-D5531RX / TC-D5531RXP / TC-D5532RX Model: Screw No.5 (2-point)

# Dimensions

Unit: mm

